



YB OUTDOORS, LLC

Kingwood, Tx 77339

713-999-2561

WWW.YB-OUTDOORS.COM



Installation

First off, we would like to thank you for your purchase! We hope you enjoy your product and help spread the word about our company and website!

Items needed for the install:

- Windex
- Isopropyl rubbing alcohol
- 3 – 4 dry towels
- Razor blade or sharp scissors
- Window needs to be clean and completely dry before installing.
- Window Velcro **WILL NEED** to be replaced, timing varies based on local weather conditions.

- **Very important – Velcro needs to be installed on the window in direct sunlight outside and left outside in the sun for a full day. Do not install in a garage, shed, or shade. Do not install if cloudy and humid or chance of rain within 6hrs of the install.**
 - Start in the mid to late morning once the dew is gone and the window is completely dry and in direct sunlight.
 - The Velcro at the corners can be cut straight or you can trim to the curve of the window if you prefer. Trimming to the curve does leave small corners on the Velcro that are more apt to lose adhesion more quickly than the square cut ends.
 - To remove the pad – use care and peel off gently. It helps to stick a pen or pencil in between the Velcro to get it started coming off.



YB OUTDOORS, LLC

Kingwood, Tx 77339

713-999-2561

WWW.YB-OUTDOORS.COM



1. Clean the window thoroughly with Windex and wipe until the window is completely dry.
2. After it dries, go over it with the alcohol and wipe completely dry. This only needs to be where the tape is going to be applied (outer 2" of the window).
3. All Velcro will be attached to the window approx. 1/8 – 1/4 of inch in from the outside edge of the window. This allows for solid adhesion to the glass.
4. The 2 long pieces are for the top and bottom of the window.
5. For the bottom – cut the piece in half and place one end in the center of the window with the bottom edge of the Velcro approx. 1/8 – 1/4 of inch up from the edge of the glass and run it out to the bottom outside corner maintaining the 1/8 – 1/4 reveal on the glass. Cut the excess Velcro at the corner and repeat for the other bottom side of the window.
6. Run the top piece across from corner to corner maintaining the 1/8 – 1/4 inch reveal on the glass and trim as needed.
7. Install the 2 upright pieces on the side and trim to fit between the top and bottom pieces.



Thanks from YB-OUTDOORS and Happy Camping!

YB Anywhere Else?